



1) Complete "Assembly Instructions" prior to installation. Roll up canopy with fiberglass installed.



2) Begin installation in front of RV.



3) Install (2) 12' anchor straps in front of RV. Notice "criss-cross" pattern.



4) Move to back of RV.



5) Attach (1) 12' strap to RV frame, ladder, hitch or bumper. Repeat with another 12' strap.



6) Leave straps lay and continue installation.



7) Pull rolled up canopy on top of the front of RV. Be sure to allow for canopy to unroll towards back of RV. Let 6' corner straps down.



8) Attach 6' to 12' straps in front of RV.



9) Loop 12' strap through middle hole.



10) Pull strap through bottom hole. Hand-tighten enough to stabilize the canopy, but allow for continued installation.



11) Begin unrolling the canopy to locate the first cross strap at the fiberglass rod.



12) Pull cross strap until velcro pieces are aligned to arch the fiberglass rod. **Damage to fiberglass rods and couplings may occur if velcro pieces are not properly aligned and attached.**



13) Continue to unroll canopy towards the back of the RV until the next cross strap is reached.
USE CAUTION TO AVOID DAMAGE TO ROOF UNITS



14) Pull cross strap until **velcro pieces are aligned** to arch the fiberglass rod. Attach velcro pieces together.



15) Try to avoid roof units. It is suggested to put cross straps towards backside of roof units, or in the direction needed to tighten the canopy.



16) Continue unrolling the canopy towards the back of the RV.

USE CAUTION TO AVOID DAMAGE TO ROOF UNITS



17) Repeat **STEPS 11-16** until the canopy is fully unrolled (with arches) to the back of the RV.



18) Once in back pull the canopy tight. Attach back straps. **REFER TO STEPS 8-10.**



19) Tighten straps carefully to avoid damage to RV. Keep straps at a 45-degree angle and **ensure they are wrapped around the corner of the RV.**



20) Avoid damage to drains, etc. **TIP: Lift corner of canopy while pulling strap tight.**



21) Repeat process in back of RV. **Ensure they are wrapped around the corner of the RV.**



22) Begin side straps.



23) Attach 12' strap to frame or brace. **DO NOT ATTACH TO PLUMBING OR PULL-OUT FRAME.**



24) Attach 12' strap to 6' strap and hand tighten. Location varies for each RV type. Side straps can be secured at the end loop of any fiberglass arch, but is preferably placed near center of RV.



25) Move to other side of RV.



26) Repeat process.



27) Avoid awnings, slide outs, etc., where possible. Straps are interchangeable.



28) In this application, we used a 12' strap on top and 6' on bottom to avoid the awning.



29) Install Velcro under buckle to protect RV.



30) Fold extra strap.



31) Enclose extra folded strap into Velcro.



32) Repeat process for front straps.



33) Repeat process for back straps.



34) Repeat process for side straps.



35) Move to other side and repeat process.



36) Notice roof unit clearance in front of RV.



37) Notice roof unit clearance in back of RV.



38) Finished Product – Side View



39) Finished Product – Front View



40) Finished Product – Back View



Enjoy your new Shade RV canopy!

Save with Shade!

Questions? Email us at:
support@shaderv.com